

## Woodside – Heating and Hot water Guide

The heating is not programmed to come during the summer months. The hot water is set continuously (it will top up the tank when it gets used and the tank keeps it insulated the rest of the time).

The heating is controlled by a Nest smart thermostat. The thermostat is located in the hallway next to the internet router.

If you want more heat, simply turn the dial up so the target temperature exceeds the current temperature. It will glow orange when it's the heating is on.

The thermostat uses internet wifi to manage the heat settings. If the internet goes down (which has only happened once in 5 years) the heating and hot water can be manually switched on by pressing the button in the middle of the Nest receiver in the boot room.



Silver rotating dial on the outside turns temperature up and down

Screen is glowing orange so heating is on



Screen is glowing blue so heating is off

Nest unit in boot room has override button to turn heating and hot water on



The hot water also has an electric immersion heater, however this should not be required as the hot water will always be hot via the Nest controller.

